


## **Probe Planarization**

#### by using Mylar Tape and Marker






## Probe Planarization Tips


- Good contact of both probe tips with the DUT is essential to accurate calibration and measurements.
- Mylar tape provides leveling guidance on flat, even surface (bare PCB).
- Color marker helps on uneven surface (solder bumps).
- A good microscope is important. You may damage the probe if you cannot see its tips well.







### Tools - Accessories



Optical Microscope (~ 90 x magnification)



USB Digital Microscope (~ 90 x magnification)



TCS70
Calibration
Substrate



Mylar Tape




Fine-tip Sharpie pen


- Using a good microscope is essential.
- You might damage the probe if you cannot see its tips well.

(Make sure to use a long working range (5 cm @ 90x) microscope!)




## Probe Planarization on Flat Surface







## Top signal tip touches down first




#### Step 1:

Land the probe tips on the tape and observe the probe-tip footprint. Above image shows that top signal tip touches the surface first.



### Bottom signal tip touches down first




#### Step 2:

Adjust the planarization knob on the TP250 positioner to level the bottom signal tip. Above image shows that bottom signal tip touches the surface first.



### Both tips touch down simultaneously




#### Step 3:

Adjust the planarization knob on the positioner to land both probe tips. Above image shows the two probe tips touch the surface evenly.



## Make good probe contact on DUT




#### Step 4:

Lower the probe tips further and observe the tips to slide forward for  $5 \sim 10$  mils (125  $\sim 250$  um) for good probe contact




# D-Probe Landing on BGA Pads




Video showing how to level the probe tips on a flat surface



### Probe Planarization on Uneven Surface









# Land Probe Tips on Solder Bumps

- Color solder bumps with a Sharpie
- Use the probe skid marks to confirm good tip contact
- Clean up the solder bumps with industrial alcohol after probing








## Use Probe Skid Marks as Guidance







Top signal tip touches down first Bottom GND tip touches down first



## Both Tips Touch Down Simultaneously






Both tips touch down simultaneously

Clean up solder bumps with industrial alcohol after probing



# S-Probe Landing on Solder Bumps



Video showing how to land the probe tips on an uneven surface



## PacketMicro Product Offering



#### PacketMicro offers one-stop shopping for your needs in PCB probing and SI analysis.

- Rugged 40/30 GHz probes
- DIY Probe Stations

CSS AITT Signal-Integrity Tool

Probe Positioners

- Junkosha phase-stable cables •
- Dino-Lite Microscopes



### PacketMicro Customers (of 200+ in 30+ Countries)







































































## Thank You

### We help make your probing tasks easy!

- Benchtop DIY Probe Stations
- Rugged 65 GHz Differential Probes
- Rugged 30 GHz Single-ended Probes
- Laboratory Rental
- Engineering Services
- Signal Integrity Consulting

#### **Contact:**

support@packetmicro.com

Office: 408-675-3900

2312 Walsh Avenue, Suite A, Santa Clara, CA 95051, USA